

# Captain's Bed Assembly Instructions

Contents: sizes vary depending on model ordered

- (A) = 1 headboard
- (B) = 1 footboard
- (C) = 2 bed rails (75" or 80" long)
- (D) = 9 slats (twin = 40-1/4", double = 55-1/4", queen = 61-1/4", king = 79-1/2" long)
- (E) = 8 connector bolts (100mm long)
- (F) = 8 cross dowels
- (G) = 18 wood screws
- (H) = 1 Allen key
- (I) = 1 centre rail (king size only)

Tools required:

- Slotted screwdriver
- #2 Robertson or Phillips screwdriver

(E) connector bolt (F) cross dowel (G) wood screw (H) Allen key



Please read all instructions before beginning

1. Assemble bed using 2 bed rails (C), 1 headboard (A), 1 footboard (B), 8 connector bolts (E), with 8 cross dowels (F). Refer to "Figure 1" for correct position of bed rail, bed end and hardware. Support rails must be on the inside of the bed.
2. King bed only: slide centre rail (I) into the slots in the headboard and footboard. If a trundle bed is being added, move the centre rail brackets off-centred as required.
3. If a drawer unit (4019A or 4919A) is being installed it should be placed on the support rails before the bolts are fully tightened.
4. Slide 9 slats (D) into bed rail grooves and secure each slat with 2 wood screws (G) using predrilled holes, refer to "Figure 2". Position 1 slat 3" from each bed end and 7 evenly spaced in between. Ensure that the spaces between slats are less than 3 1/2".

