



## 1302 & 1303 ASSEMBLY INSTRUCTIONS

### CAUTION

**This can be a dangerous operation if the instructions are not followed precisely!**

#### Tools required:

Hammer, #2  
Robertson or  
Phillips  
screwdriver

#### Contents:

- |  |                         |
|--|-------------------------|
| A. 1 – Back  | B. 1 – Front rail       |
| C. 2 – Arms  | D. 12 – 3" wood screws  |
| E. 12 – Wood plugs   | F. 6 – 1 ½" Wood screws |
| M. 1 – Mechanism (plus mattress, back fabric & seat cushions.) |                         |

**Reverse all steps for dis-assembly. Please read instructions completely prior to starting.**

1. Place the mechanism "M" on the floor, with the back placed as you will want the sofa bed.
2. Fasten the first arm "C" to the front rail "B", use 3 screws "D" in holes "H", as shown in the drawing. (Bottom inside edge of the front rail is not "rounded").
3. Fasten the second arm "C" to the other end of front rail "B", in the same manner.
4. Place the back between the arms (upholstery mounting blocks "J" are close to the top), top flush with the top of the arms (off the floor approximately ½"). Fasten both arms to the back using 3 screws "D" at each end, in holes "G", as shown in the drawing.
5. Install 12 wood plugs "E" in screw holes. Tap gently with hammer until flush with the surface.
6. Lift the mechanism slots "K" onto the mounting screws in the arms and slide forward, tight against the front rail "B".
7. Install one screw "F" through the mechanism into the front rail at each end.
8. Untie and open the mechanism. (*For dis-assembly tie the handle to the bottom cross wire*)
9. Tighten the mounting screws. Install 2 screws "F" through the mechanism into each arm.
10. Place the mattress on the mechanism. Read the mechanism instructions and close it.
11. Insert the back fabric into the mounting blocks "J" & place the seat cushions.

